

FLOORS

Protection from ground moisture and insects

A floor increases the comfort of the Nordic tipi and protects against moisture and insects. In our range, there are floors to fit in every Nordic tipi. The combinations with half floors and inner tents offer comfortable and flexible solutions for your needs. The opening in the middle of the floor makes it possible to light a fire in the tent. The floors are easy to use and do not need to be detached when packing. During assembling, the floor is adjusted with a stretching device for a nicely stretched and tight-fitting floor.



Floors

Tentipi[®] whole floors are available in two grades – Pro and Comfort. Either grade of floor can be used with any of our tent models except Olivin. The zips make it possible to open the floor in different ways. A tensioning device fitted to the outer tent improves the seal between the floor and the tent walls, helping to keep insects out.

Floor and use of fire

It is possible to use an open fire or stove in a Nordic tipi with floors in both Pro and Comfort class. For using a fire with the whole floor, the four zips are opened and the wedges are folded under the floor so that an O-opening is formed as shown. The opening can be opened even further if you want more bare ground in the tent for storage of wet shoes for example.



Examples of openings



Open from the centre and outwards. This allows you to brush off bread crumbs on the ground rather than on the floor. Also enables use of stove or open fire.



Open from the centre and outwards but without opening the zip by the door. Allows crumbs to be brushed onto the ground while making more dry storage space by the door. O+A-opening for secure use of an open fire or stove.

V-opening



on the tent floor. A large opening from the door and round the

Open from the door. To avoid having dirty boots

central pole. For wood storage, open fire or to have ground contact. (Only Floor Pro.)





Floor Pro

Made of light, strong, high tenacity polyamide fabric which is much stronger than standard fabrics. Need not be detached when packing the tent. The floor has four zips which allow flexible opening possibilities for secure use of an open fire or stove.

Openings: O, A, O+A, V, U

Floor Comfort

Made of carefully chosen standard-type material. Need not be detached when packing the tent. The floor has four zips which allow flexible opening possibilities for secure use of an open fire or stove. (U-shaped opening is not possible on the floor in Comfort class.)

Openings: O, A, O+A, V

Floors	Pro			Comfort			
Size	5	7	9	5	7	9	15
Weight (kg)	1.3	1.7	2.2	1.1	1.5	1.9	2.5
Article number	11005	11007	11009	12050	12070	12090	12150




Half floors

Tentipi[®] half floors are available in Comfort grade. If the Nordic tipi is used with a half inner tent, you can have a half floor on the rest of the living area. With no inner tent, a whole floor can be made by using Velcro to join two halves of ordinary material or half ordinary/half fleece.

Half floor and use of fire

To make a fire in the tent, you can fold away the floor by opening the zip in the middle. The zip also makes it possible to remove a quarter of the floor to create an uncovered space for dirty shoes, firewood, etc. Note that fire or stove is not allowed with half fleece floor or in combinations with half inner tents.







Half floor Comfort

Made of a carefully chosen standard-type material. Need not be detached when packing the tent. The zip makes it possible to open up the floor to make a fire or to use a quarter floor. Half floor can be combined with a half inner tent or combined with a second half floor to make a whole floor.

Half fleece floor Comfort

Made of a carefully chosen standard-type material where one side is covered with soft and comfortable fleece. It is fully damp-resistant, like all our other floors. Need not be detached when packing the tent. A zip in the middle makes it possible to remove a quarter of the floor. Half fleece floor can be combined with a half inner tent or combined with a second half floor to make a whole floor. Note that fire or stove is not allowed with half fleece floor.

Half floors	Half floor	Comfort	Half fleece floor Comfort		
Size	7	9	7	9	
Weight (kg)	0.8	1.0	1.9	2.6	
Article number	12270	12290	12170	12190	





Tentipi AB, Verkstadsgatan 15, SE-686 30 Sunne, Sweden +46 (0)960 300 00 | www.tentipi.com | info@tentipi.com